

HANDLER

Download our Catalogs
DENTAL JEWELRY

Over 85 Years of Service
CREATIVE INNOVATION AND QUALITY MANUFACTURING

FIND YOUR PART
A B C D E F G H I J K L M
N O P Q R S T U V W X Y Z

213 CERAMIST BENCH

Shipping Wgt.: 270 lbs. [122.4 Kg]
Unit Dimensions: 58" wide x 24 1/2" deep x 32" to work surface [147cm x 62cm x 81cm]. Bench contains 58" wide x 6 1/2" deep x 6" high riser [147cm x 17cm x 15.2] mounted rear

HOME NEWS & PRESS SUPPORT & FAQs LAB LAYOUTS INTERNATIONAL ORDER CONTACT US

Dental
Jewelry
Industrial
Hobby/Craft
Podiatry
Audiology

Red Wing Polishing Motors have been manufactured by Handler for over 80 years.

While providing a variety of horsepower ratings and speeds for the technician, Red Wing motors are known the world over for quality, dependability and affordability. Precision turned shafts made of alloy steel and double shielded ball bearings insure the smooth movement of both tapered and straight shafts.

When introduced in 1920, Red Wing motors provided the precision and torque required by the dental and industrial trades. We are certain you will find Handler Red Wing motors the quiet, strong producer for your lab or manufacturing facility.



26A Red Wing Lathe
A full 1/4 HP, 1725/3450 rpm lathe for use on top of laboratory bench (115 Volts/60Hz). Its 4 1/2" [11.4cm] shaft height allows for easy use by the technician with hands resting on the tabletop. Shipped with standard dental, tapered shafts, each lathe includes a right and left chuck remover, which provides ease of removal of standard dental chucks.

The 26A is manufactured to provide years of durable service while being utilized for such operations as polishing and grinding. This unit may be supplied with 1/2" [1.3cm] straight shafts when specified.

Available in 115 Volts/50Hz, 220/50Hz and 220/60Hz at additional charge.

NOTE: Specify No. 26AS for motor with 1/2" [1.3cm] straight shafts.

Shipping Wgt.: 39 lbs [17.7 Kg]

Unit Dimensions: 15 1/2" long x 7 7/8" wide x 7 1/4" high [39cm x 20cm x 18cm]



26 Red Wing Lathe
A full 1/4 HP, 1725/3450 rpm two speed polishing lathe with 6" [15.2cm] shaft height (115 Volts/60Hz). Designed and built for use as a polishing lathe, its tapered shafts will accept standard dental tapered chucks.

The 6" [15.2cm] shaft height of the 26 will allow the technician to utilize larger diameter buffing wheels for pumice and dry polishing operations. This unit may be supplied with 1/2" [1.3cm] straight shafts when specified.

Available in 115 Volts/ 50Hz 26A, 220 Volts/50Hz 26E and 220 Volts/60Hz 26C at additional charge.

NOTE: Specify No. 26S for motor with 1/2" [1.3cm] straight shafts.

Shipping Wgt.: 41 lbs [18.6 Kg]

Unit Dimensions.: 15 1/2" long x 8" wide x 9" high [39cm x 20cm x 23cm]



27 Red Wing Lathe
A full 1/4 HP single speed 3450 rpm polishing motor with a 6" [15.2cm] shaft height (115Volts/60Hz). Designed to be utilized by the technician who desires a single speed polishing motor where a 3450 rpm speed is used exclusively for polishing. This unit may be supplied with 1/2" [1.3cm] shafts when specified.

Available in 115 Volts/50Hz, 220 Volts/50Hz and 220 Volts/60Hz at additional charge.

NOTE: Specify No. 27S for motor with 1/2" [1.3cm] straight shafts.

Shipping Wgt.: 41 lbs [18.6 Kg]

Unit Dimensions.: 15 1/2" long x 7 7/8" wide x 7 1/4" high [39cm x 20cm x 18cm]

28L Red Wing Lathe
A 1/3 HP two speed 1725/3450 rpm polishing motor with 4 1/2" shaft height. Built for the technician who requires additional torque, the 28L contains standard dental tapered shafts with chuck removers. This durable motor will provide



years of service for your laboratory.
 Available in 115 Volts/60Hz as a standard product, the 28L is also built in 115 Volts/50Hz 28D, 220 Volts/50Hz 28E and 230 Volts/60Hz 228L-E at additional charge.
 NOTE: Specify No. 28LS for motor with 1/2" [1.3cm] straight shafts.
 Shipping Wgt.: 40 lbs [18.1 Kg]
 Unit Dimensions.: 15 3/4" wide x 7 7/8" deep x 7 1/2" high [40cm x 20cm x 18cm]



28H Red Wing Lathe
 A 1/3 HP two speed 1725/3450 rpm high base polishing motor with 6" shaft height . Built to accommodate larger diameter buffs and chuck accessories, the 28H provides added torque for the frequent polisher. The unit is shipped with standard dental tapered shafts with chuck removers.
 Available in 115 Volts/60Hz and 115 Volts/50Hz, 220 Volts/50Hz and 220 Volts/60Hz at additional charge.
 NOTE: Specify No. 28HS for motor with 1/2" [1.3cm] straight shafts.
 Shipping Wgt.: 42 lbs [19.5 Kg]
 Unit Dimensions.: 15 3/4" wide x 7 7/8" deep x 8 3/4" high [40cm x 20cm x 22.2cm]



29 Red Wing Motor
 A full 1/2 HP single speed 3450 rpm polishing motor with 6 3/8" [16.2cm] shaft height (115 Volts/60Hz). Built for heavy use by the technician and polisher, the rugged polishing motor will provide years of trouble free service. The 29 is manufactured with 1/2" [1.3cm] straight shafts, and is shipped complete with one each left and right #20 tapered chucks. Ideal for the laboratory or manufacturer who performs constant polishing or grinding operations.
 Available in 220 Volts/60Hz and 220 Volts/50Hz at additional charge.
 Shipping Wgt.: 45 lbs [20.4 Kg]
 Unit Dimensions.: 18 1/2" long x 7 3/4" wide x 9" high [47cm x 20cm x 23cm]



29A Red Wing Motor
 A full 3/4 HP single speed 3450 rpm polishing motor with 6 3/8" [16.2cm] shaft height (115 Volts/60Hz). Built for extra heavy duty use by the dental technician or industrial polisher, who requires extra torque.
 The 29A is manufactured with 1/2" [1.3cm] straight shafts, #20 tapered chucks for use with large buffs, brushes and similar chucks.
 Available in 220 Volts/60Hz and 220 Volts/50Hz at additional charge.
 Shipping Wgt.: 47 lbs [21.3 Kg]
 Unit Dimensions.: 18 1/2" long x 7 3/4" wide x 9" high [47cm x 20cm x 23cm]



Warranty Information | Return Policy [800.274.2635](tel:800.274.2635)
 COPYRIGHT © 2005 HANDLER MANUFACTURING & GEMINI DESIGN LLC. ALL RIGHTS RESERVED